

NFPA No.

312

Fire Protection of VESSELS DURING CONSTRUCTION 1964



Fifty Cents

Copyright © 1964

NATIONAL FIRE PROTECTION ASSOCIATION
International

60 Batterymarch Street, Boston, Mass. 02110

3M-6-64-WP

Printed in U.S.A.

National Fire Protection Association

International

The National Fire Protection Association was organized in 1896 to promote the science and improve the methods of fire protection. Anyone interested may become an Associate Member; the annual dues are \$20.00. National and regional societies and associations are eligible to be Organization Members. Full membership information is available on request.

This is one of a large number of publications on fire safety issued by the Association. All NFPA codes, standards, and recommended practices are prepared by NFPA Technical Committees and adopted at an Annual Meeting of the Association. They are intended to prescribe reasonable measures for minimizing losses of life and property by fire.

This and other NFPA codes, standards, and recommended practices are published in the **National Fire Codes**, a compilation of NFPA's official technical material. Write the Association for full information.

Official NFPA Definitions

Adopted Jan. 23, 1964. Where variances to these definitions are found, efforts to eliminate such conflicts are in process.

SHALL is intended to indicate requirements.

SHOULD is intended to indicate recommendations or that which is advised but not required.

APPROVED means acceptable to the authority having jurisdiction. The National Fire Protection Association does not approve, inspect or certify any installations, procedures, equipment or materials nor does it approve or evaluate testing laboratories. In determining the acceptability of installations or procedures, equipment or materials, the authority having jurisdiction may base acceptance on compliance with NFPA or other appropriate standards. In the absence of such standards, said authority may require evidence of proper installation, procedure or use. The authority having jurisdiction may also refer to the listings or labeling practices of nationally recognized testing laboratories,* i.e., laboratories qualified and equipped to conduct the necessary tests, in a position to determine compliance with appropriate standards for the current production of listed items, and the satisfactory performance of such equipment or materials in actual usage.

*Among the laboratories nationally recognized by the authorities having jurisdiction in the United States and Canada are the Underwriters' Laboratories, Inc., the Factory Mutual Engineering Division, the American Gas Association Laboratories, the Underwriters' Laboratories of Canada, the Canadian Standards Association Testing Laboratories, the Canadian Gas Association Approvals Division, and Yacht Safety Bureau.

LISTED: Equipment or materials included in a list published by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment or materials, and whose listing states either that the equipment or material meets nationally recognized standards or has been tested and found suitable for use in a specified manner.

LABELED: Equipment or materials to which has been attached a label of a nationally recognized testing laboratory that maintains periodic inspection of production of labeled equipment or materials, and by whose labeling is indicated compliance with nationally recognized standards or the conduct of tests to determine suitable usage in a specified manner.

AUTHORITY HAVING JURISDICTION: The organization, office or individual responsible for "approving" equipment, an installation, or a procedure.

Copyright and Republishing Rights

This publication is copyrighted© by the National Fire Protection Association. Permission is granted to republish in full the material herein in laws, ordinances, regulations, administrative orders or similar documents issued by public authorities. All others desiring permission to reproduce this material in whole or in part shall consult the National Fire Protection Association.

Multiple Copy Price Reduction For Six or More Copies Available on Request.

Recommendations for

FIRE PROTECTION OF VESSELS DURING CONSTRUCTION, REPAIR AND LAY-UP

NFPA No. 312 — 1964

1964 Edition of No. 312

These Recommendations were prepared by the Sectional Committee on Shipbuilding, Repair and Lay-Up with the concurrence of the Committee on Marine Fire Protection. They were adopted by the Association at its 68th annual meeting in May, 1964. This edition supersedes that of 1951, of which it is a revision.

Origin and Development of No. 312

The first standard on these subjects was adopted by the NFPA in 1933 on recommendation of its Marine Committee, predecessor of the Marine Section. It was further considered in 1935, 1936, and 1937, and was finally adopted by the Association in 1938 on recommendation of the Marine Section Committee on Builders' Risk, Repair and Lay-Up. That edition was reprinted in 1942 with editorial changes.

With the reorganization of NFPA marine activities in 1948, responsibility for these recommendations fell to the Committee on Shipbuilding, Repair and Lay-Up. Their revised recommendations were adopted by the Association in 1950 (Parts I and II) and 1951 (Part III). This 1964 edition is an extensive revision of the 1950-51 text.

Sectional Committee on Shipbuilding, Repair and Lay-Up

Edwin M. Hood, Chairman,

Shipbuilders Council of America, 1730 K Street, N.W., Washington, D. C. 20006

E. W. Costello, Todd Shipyards Corp.
(Personal)

George W. Dawson, Vlachos & Company. (Personal)

Jesse C. Jones, Marine Chemists' Assn.

J. R. Lindgren, United States Salvage Assn., Inc.

W. F. Metts, Newport News Shipbuilding and Dry Dock Co. (Personal)

H. E. St. Clair, U. S. Department of Commerce, Maritime Administration.

E. T. Schneider, Bethlehem Steel Co. (Personal)

John F. Smith, Jr., Atlantic & Gulf Coasts Drydock Assn.

Committee on Marine Fire Protection

Thomas M. Torrey, *Chairman*,

Insurance Co. of North America, 79 John St., New York, N. Y. 10038 (Personal)

Charles S. Morgan,† *Secretary*,

National Fire Protection Assn., 60 Batterymarch St., Boston, Mass. 02110

Braxton B. Carr, The American Waterways Operators, Inc.

Joseph E. Choate, National Assn. of Engine & Boat Mfrs.

R. Cox, Fire Equipment Manufacturers Assn.

Alan Cumyn, Board of Steamship Inspection, Department of Transport.

Frank W. Dunham, Jr., American Assn. of Port Authorities.

F. J. Fee, Jr., National Automatic Sprinkler & Fire Control Assn.

Frank Grafton, U. S. Department of Commerce, Maritime Administration.

Rear Admiral Frank D. Higbee, USCG (ret.) (ex-officio), Chairman, Sectional Committee on Harbor Emergency Organization.

Vice Admiral James A. Hirshfield, USCG (ret.), Lake Carriers' Assn.

Edwin M. Hood (ex-officio), Chairman, Sectional Committee on Shipbuilding, Repair and Lay-Up.

George W. Morgan, Assn. of American Ship Owners.

Capt. Harry J. Parker, National Cargo Bureau, Inc.

Roy C. Petersen (SFPE) (ex-officio), Chairman, Sectional Committee on Operation of Marine Terminals.

Rear Admiral O. C. Rohnke, United States Coast Guard.

Rear Admiral H. C. Shepheard, USCG (ret.), Washington 6, D. C. (Personal)

J. Robert Snyder, Pacific Maritime Assn.

Sydney Swan (ex-officio), Chairman, Sectional Committee on Gas Hazards.

John M. Tecthon, Marine Chemists' Assn.

E. S. Terwilliger (ex-officio), Chairman, Sectional Committee on Motor Craft.

J. Paul Thompson, U. S. Salvage Assn., Inc.

Pierre R. Vallet (ex-officio), Chairman, Sectional Committee on Marinas and Boatyards.

T. T. Wilkinson, American Petroleum Institute.

Alternates.

Stanley Beckett, Canadian Dept. of Transport. (Alternate to A. Cumyn.)

B. H. Lord, Jr., American Petroleum Institute. (Alternate to T. T. Wilkinson.)

†Nonvoting member

**Recommendations for
FIRE PROTECTION OF VESSELS
DURING CONSTRUCTION, REPAIR,
AND LAY-UP.
NFPA No. 312 — 1964**

INTRODUCTION.

Owing to the quantity and character of combustible materials used in the construction of many vessels, such vessels in course of construction and during repair are readily vulnerable to fire. Long alleyways, unenclosed stairways, hatches and hoistways facilitate the rapid spread of fire throughout the vessel. The location of the shipyard is frequently so isolated that dependence for fire fighting is mainly on the private protection provided. Even where major municipal protection is available, the possible delayed response due either to lateness in the discovery of the fire or the absence of means for quick notification, lack of special equipment in many municipal fire departments for combating shipboard fires, or an unfamiliarity with ship construction due to the transitory nature of the risk may cause material damage or complete destruction before effective means of extinguishment can be brought into action. It is, therefore, obvious that every reasonable means of preventing fire should be provided and supplemented by such means of detection and protection equipment as will permit the prompt discovery, retard the spread, and permit extinguishment of any fire before it has passed the incipient stage. To this end the adoption of the following recommended safeguards is urged.

1. VESSELS IN COURSE OF CONSTRUCTION

101. Rubbish and Waste Materials.

1011. Vessels, shipways and outfitting piers should be kept as clean as conditions will permit. All accumulations, and particularly combustible rubbish, refuse and waste materials, should be collected and safely disposed of promptly and at least once each shift as the work progresses. Areas in which hazardous work is to be done should be in a clean condition before such work is started.

1012. Furniture and other equipment usually crated or packed in excelsior or similar packing materials should be uncrated or removed from packing in a safe location, preferably well removed from vessels. All packing materials should be disposed of promptly and safely.

1013. Temporary protective coverings such as tarpaulins which may be used to protect machinery, equipment, combustible stores or similar materials should either be of noncombustible material or properly flame-proofed.

102. Smoking.

1021. Smoking should be prohibited except in locations specifically designated as smoking areas and approved by management or authority having jurisdiction.

103. Storage of Explosive and Flammable Materials.

1031. The storage of explosive, highly flammable or combustible materials should not be permitted on vessels in course of construction, nor in close proximity to the ways and outfitting berths. This should not be construed to prevent the storage of such quantities as may be necessary for the normal progress of the work, provided such storage is arranged so as not to obstruct fire-fighting operations.

104. Use of Open Flame or Spark Emitting Devices.

1041. It should be the responsibility of the superintendent directly or through his designated assistants, to determine that any hot work requiring the use of riveting, welding, burning, heating or other fire or spark producing operations may proceed with safety. Special attention is called to the danger of hot work in freshly painted areas, in refrigerated spaces, in close proximity to combustible stores or other materials and similar locations. Steps should be taken to assure that all open fires are secured during meal times and that all fires are extinguished at the close of the work period.

1042. It is particularly important that employees check the opposite sides of bulkheads or decks on which hot work is to be done, to be certain that there are no combustible materials, painted surfaces, wiring runways, etc., in contact with or in close proximity to such bulkheads or decks which may be damaged by heat or fire. Where there is any danger of starting fires in the way of hot work, despite the fact that other ordinary precautions are employed, a fire watch should be provided to stand by during such operations with portable fire fighting equipment ready to extinguish any incipient fire that may occur.

1043. Riveting furnaces should be located with due regard for the safety of any combustible materials nearby. All fires in rivet-heating furnaces or pots should be extinguished at the close of each shift. Attention is called to the need for adequate ventilation in confined spaces where riveting furnaces are used.

1044. Before any hot work involving riveting, welding, burning, heating or other fire or spark producing operations is started in or on any fuel spaces or other areas which contain or have contained flammable or combustible liquids or vapors, certification of such areas should be obtained in accordance with the Standard for the Control of Gas Hazards on Vessels to be Repaired (NFPA No. 306). Attention is called to the hazards of gasoline in the tanks of motor-driven life boats.

1045. Equipment such as blow torches, cutting and welding apparatus should be stored at the close of each day's work as to prevent tampering by unauthorized persons. Oxygen, acetylene and other flammable gas lines should be disconnected at the source of supply at the end of each working shift, and the discharge end of the hose removed from below decks or enclosed spaces.

1046. Heating for the personal comfort of employees or for other reasons should be done by means of steam, hot water, or electricity using the vessel's heating facilities so far as practicable. Where salamanders must be used they should be mounted on 4-inch legs and be of the coal- or coke-burning type, and should be permitted only where someone is constantly in attendance. They should be located a safe distance from combustible materials and so arranged as to avoid any danger of upset. Under no conditions should compressed air or oxygen be discharged into salamanders to increase the rate of burning. Attention is called to the need for adequate ventilation in confined spaces where salamanders are used.

1047. Only oxygen, acetylene or other flammable gas hose in good repair should be used. Where gases are supplied from portable

cylinders, the latter should not be placed below the main deck, in confined spaces, or under overhanging decks. Oxygen, acetylene, and other flammable gas lines should be disconnected at the source of supply at the end of each working shift, and the discharge end of the hose removed from below decks or confined spaces. Portable outlet headers from piped systems should comply with the provisions of NFPA No. 51, Standard for the Installation and Operation of Oxygen-Fuel Gas Systems for Welding and Cutting.

1048. Electric welding cables should be inspected frequently and cables with damaged insulation should be reinsulated or replaced. Cables should be triced up off steel decks, bulkheads, etc., wherever possible to reduce the possibility of short-circuiting or grounding. When not in use, electrodes should be removed from holders and the holders so placed that they will not cause arcing or electrical short circuits.

105. Application of Paints and Other Flammable Compounds.

1051. No welding, burning, or other open flames or spark-producing machines or operations such as chipping, grinding, etc., should be permitted in close proximity to the application of flammable paints or other flammable compounds. Adequate ventilation should be provided in such areas as deemed necessary to maintain the atmosphere at not more than 10 per cent of the lower explosive limit or below the lower limit of toxicity for that particular material. In all instances, precautions and application instructions of the manufacturer should be observed. Where artificial lighting is needed in hazardous areas, only approved explosion-proof lights should be used.

106. Temporary Electrical Installations.

1061. Electrical wiring and equipment of a temporary nature should be substantially installed in such manner as to be safe from physical damage, and should be inspected frequently. Defects in wiring, fixtures, or equipment of a type liable to create dangerous conditions should be promptly remedied. Portable equipment should be provided with overcurrent protection such as fuses or circuit breakers and should be disconnected when not in use. Except where lights are required for inspection purposes, electric current to the vessel's lighting system should be cut off when no work is being done. All electric lines should be kept triced up off the decks wherever possible.

107. Protection to Door Openings.

1071. As construction progresses, so far as practicable, all door openings should be provided with their permanent doors.

1072. In order to minimize the spread of fire, it is essential that all doors, including draft stop doors, fire screen doors and watertight bulkhead doors, be kept closed when work is not in progress. So far as practicable, care should be taken that the closing of these openings is not obstructed or prevented by hose and pipe lines, electric connections, or other lines. Provisions for disconnecting such lines should not be considered as a satisfactory alternative. All other openings through bulkheads such as vent ducts should be kept closed off during the course of construction, wherever practicable.

1073. Where doors to quarters are kept locked to prevent theft or unauthorized entry, the keys should be made available to the watchman and fire brigade, or should be located at a designated place aboard where they can be obtained without delay in emergencies by such personnel.

108. Staging.

1081. Staging other than steel or fire-retardant treated wood should be removed as soon as its purpose has been served. It is recommended that combustible staging materials be treated with an approved flame-retardant compound to resist ignition from sparks and to retard the spread of fire. Small buildings or similar structures on or under shipways should be restricted to those absolutely necessary, and should be of noncombustible construction.

109. Watch Service.

1091. During the outfitting period a competent watchman should be on duty aboard the vessel at all times. It is recommended that there be installed on the vessel an approved watchman supervisory system of watch boxes connected to a central office where watchmen's signals will be received.

1092. Where watch systems such as described in 1091 are not feasible or are not deemed necessary, an approved watchman's portable clock system should be provided during the outfitting period.

1093. Such watch service may also be necessary on the shipways during earlier stages of construction depending upon the degree of completion of vessels, combustibility of ways, stocks and staging, and the obstruction or congestion caused by the proximity of adjacent ways.

1094. Before going on duty, watchmen should be informed of locations where riveting, welding, burning or other hot work has been carried on in the vicinity of combustible material during the previous work period. They should also be advised of the locations of freshly painted areas, tanks containing oil, or other hazardous conditions. All such locations should be inspected during the progress of the work and as soon as practicable after work has been stopped. The regular watch force should be assisted by other competent persons when necessary in order to complete the inspection within a reasonable period. The watchmen should be required to give further special attention to these locations during their rounds so as to ensure against the spread of any previously undetected fires.

1095. Watchmen should be familiar with the location of all items of fire equipment on vessels, and should inspect them during their daily tours of inspection.

1096. Careful selection of watchmen is emphasized. Alertness, quick reaction, perfect hearing and sense of smell, good eyesight, bodily agility and good health are indispensable requirements for a competent watchman.

110. Fire Alarm Service.

1101. At yards where private fire alarm systems are provided, temporary private fire alarm boxes should be installed on or near vessels under construction. Where private fire alarm or central station supervised watchman's system is not provided, telephones should be made available at convenient locations on or near vessels and connected to a central office where someone is constantly on duty, who is charged with the responsibility of and provided with suitable means for promptly summoning public or private fire-fighting facilities.

111. Fire Protection Equipment.

1111. Water for fire extinguishing purposes should be available to all parts of vessels under construction. 1½-inch and 2½-inch hose lines of adequate length connected to shore hydrants or hose connections should lead to points on vessels convenient for use in an emergency. Adequate supplies of spare hose and nozzles should be readily available. Due regard should be had for the capacity of existing shore hydrants to assure that an adequate water supply is available when all existing outlets are in use.

1112. During the construction of large vessels, it is recommended that temporary pipe risers with hose connections be installed at the shipways and that a supply of hose be available at such connections on the various decks of vessels under construction. These risers should be installed in the ratio of one for each 200 feet of length of the vessel. For vessels at outfitting piers, hose lines should be provided in this same ratio.

1113. Where automatic sprinklers are installed as part of a vessel's permanent fire equipment, they should be progressively placed in service as they are installed.

1114. There should be provided at convenient locations throughout vessels, approved portable fire-fighting and extinguishing appliances such as hand extinguishers in suitable numbers, and emergency breathing apparatus. The location of such equipment should be suitably designated. This may be done effectively by red lights, continuously lighted when electric current is in service on vessels.

1115. Equipment should be available for extinguishing large Class B and Class C fires* which cannot be controlled by the limited capacity of portable hand extinguishers.

112. Fire Brigade.

1121. Except where a private fire department with paid members is separately employed, designated employees should form the nucleus of a fire brigade, and should be thoroughly drilled in the use of the extinguishing equipment provided, including the laying of hose lines, the handling of hose streams and special extinguishing equipment, and the use of self-contained breathing apparatus. Drills should be held at least once a month. For further details, refer to NFPA No. 27, Private Fire Brigades.

113. Mooring at Outfitting Piers.

1131. When vessels are at outfitting piers it is recommended that all openings below weather decks not in use for access or ventila-

*Class B Fires may be defined as fires in flammable and combustible liquids, greases, etc., where a *blanketing* effect is essential.

Class C Fires may be defined as fires in electrical equipment, where the use of a *nonconducting* extinguishing agent is of first importance.

tion be kept closed as far as practicable. Where more than one vessel is at the same pier or in the same wet basin, provision should be made for the withdrawal of any vessel in the event that fire may make such withdrawal necessary.

1132. On vessels afloat, all practicable and reasonable measures should be taken to insure maximum stability. After an outbreak of fire, at the first indication of lack of stability, the discharge of fire streams should be reduced to the minimum necessary to prevent the spread of fire. Effective means to prevent overturning of the vessel should be undertaken as soon as the extent of the fire indicates there will be danger of lack of stability.

NOTE: One 2½-inch hose with standard ⅞-inch nozzle at 100 psi main pressure delivers 200 gpm or 50 tons of water per hour.

2. VESSELS UNDER REPAIR.

201. Inspection.

2011. Vessels enter repair yards in various conditions, the nature of which cannot be determined until an inspection has been made. This should be done by a responsible and qualified employee together with a representative of the owner of the vessel as soon as practicable after vessels enter a yard, and in any case before repair work is started. Such inspection should note housekeeping conditions, including location of dunnage and trash; the kind and amount of cargo aboard; and the type, amount and condition of the vessel's fire equipment.

2012. With the assistance of a ship's officer, determination should be made of the kinds and amounts of fuel oils or other flammable liquids in all cargo, bunker, deep, settler, and double bottom tanks. On all vessels and especially passenger vessels, the location and amount of combustibles such as dry stores, provisions, concentrations of mattresses and other bedding, life preservers, etc., should be determined.

2013. The information obtained should be distributed to the departments responsible for the fire safety of vessels while in the yard, and to the various production departments which are to make repairs to the vessels.

2014. For voyage repairs to be made at the outfitting dock, the inspection may be limited to the actual working area and adjacent compartments. The supplementary information necessary for fire preplanning should be obtained in all instances.

202. General Care and Cleanliness.

2021. All combustible materials, stores, dunnage, and trash in way of hazardous repair work should be moved to a safe location, or preferably, removed from the vessels.

2022. Temporary protective coverings such as tarpaulins, which may be used to protect machinery, equipment, combustible stores or similar materials should either be of noncombustible material or properly flameproofed.

2023. Wherever practicable, all oil and other flammable liquids should be removed from vessels while in repair yards.

2024. Only nonsparking tools should be used in opening piping, pumps, valves, etc., carrying flammable liquids or gases and which have not been certified as "gas-free."

2025. Smoking should be prohibited except in locations specifically designated as smoking areas and approved by management or authority having jurisdiction.

203. Storage of Explosives or Other Dangerous Cargo.

2031. Vessels carrying explosives or other dangerous cargo, excepting standard ships' stores, should not be permitted to enter a repair yard until such materials have been removed.

2032. Emergency exception: Nothing in this document should be construed as prohibiting the immediate drydocking of a vessel whose safety is imperiled, as by being in a sinking condition or by having been seriously damaged. In such cases, however, all necessary precautionary measures should be taken as soon as practicable.

204. Riveting, Welding and Other Hot Work.

2041. Attention is called to Section 104 of this document. All applicable paragraphs thereunder should be complied with for ship-repairing operations as well as by ship-building yards.

2042. Prior to the start of any welding or burning operations, employees should ascertain that conditions in the area are safe to proceed with such operations. On refrigerated ships it may be necessary to remove combustible insulation for a safe distance from the location where welding or burning is to be done, and special care must be taken to prevent sparks or hot slag from entering exposed insulated spaces. Equipment and materials in way of hot work which cannot be moved should be protected as prescribed in Paragraph 2022. Doorways, hatch and tank openings, portholes, etc., should be protected where there is danger of sparks or hot slag dropping or ricocheting into such openings and igniting combustible materials. Hot work should not be done on vessels where there is danger of sparks or hot slag falling into any oil slicks on the waters beneath.

2043. It is particularly important that employees check the opposite sides of bulkheads or decks on which hot work is to be done, to be certain that there are no combustible materials, painted surfaces, wiring runways, etc., in contact with or in close proximity to such bulkheads or decks which may be damaged by heat or fire.

2044. Where hot work processes cannot be properly safeguarded in making necessary repairs, such repairs should be accomplished by safer means, such as by drilling, sawing, bolting, or other appropriate means.

205. Heating.

2051. Heating for the personal comfort of employees or for other reasons should be done by means of steam, hot water, or electricity, using the vessel's heating facilities so far as practicable.

2052. Where salamanders must be used they should be mounted on 4-inch legs and be of the coal- or coke-burning type, and should be permitted only where someone is constantly in attendance. They should be located a safe distance from combustible materials and so arranged as to avoid any danger of upset. Under no conditions should compressed air or oxygen be discharged into salamanders to increase the rate of burning. Attention is called to the need for adequate ventilation in confined spaces where salamanders are used.

206. Application of Paints and Other Flammable Compounds.

2061. No welding, burning or other open flames or spark-producing machines or operations such as chipping, grinding, etc., should be permitted in close proximity to the application of flammable paints or other flammable compounds. Adequate ventilation should be provided in such areas as deemed necessary to maintain the atmosphere at not more than 10 per cent of the lower explosive limit or below the lower limit of toxicity for that particular material. In all instances, precautions and application instructions of the manufacturer should be observed. Where artificial lighting is needed in hazardous areas, only approved explosion-proof equipment should be used.

207. Watch and Fire Alarm Service.

2071. On inactive vessels berthed at repair yards with few or no crew members aboard the provisions of Section 109 should be observed in the conduct of all major conversions and major repair operations.

2072. At yards equipped with private fire alarm systems, it is desirable to install one or more temporary fire alarm boxes on or near the vessels. The fire alarm boxes on piers and in the yards should be plainly marked so as to be located easily. Where fire alarm systems are not provided, telephone service should be conveniently located on or near each vessel.

208. Fire Protection Equipment.

2081. While vessels are at piers or in dry dock, it is recommended that temporary hose lines supplied by shore connections be placed

aboard vessels connected and ready for use, in the ratio of at least one hose line for each 200 feet of length of vessel. Where this may be deemed unnecessary due to the size and type of vessel involved, hose lines should be provided at the piers or dry docks. These lines should be nominal 1½-inch or 2½-inch in size, or a combination of both sizes, and of sufficient length so that any part of the vessel may be reached by at least one line. Due regard should be had for the capacity of existing shore hydrants to assure that an adequate water supply is available when all existing outlets are in use.

2082. It is recommended that the vessel's fire system piping be connected to water supplies from the yard by means of temporary shore to ship connections. Caution should be used in turning on these water supplies at shore connections until it is determined that the vessel's fire system piping is intact and will not result in flooding any portion of the vessel.

2083. It is recommended that in addition to the vessel's facilities at least two portable extinguishers suitable for Class B fires be placed aboard. Additional extinguishers for Class A, B and C fires* may be required aboard depending upon such factors as the location, nature and extent of the repair or conversion work and the construction of the vessel. Hose lines (¾-inch size) supplied from shore connections provide very satisfactory first aid protection for Class A fires.

NOTE: CLASSIFICATION OF FIRES: For all practical purposes there are three general classes of fires:

Class A fires, defined as fires in ordinary combustible materials such as wood, cloth and paper where the "quenching-cooling" effect of quantities of water or solutions containing large percentages of water is most effective in reducing the temperature of the burning material below the ignition temperature and is, therefore, of first importance.

Class B fires, defined as fires in flammable petroleum products or other flammable liquids, greases, etc., where the "blanketing-smothering" effect of oxygen-excluding media is most effective.

Class C fires, defined as fires involving electrical equipment where the electrical nonconductivity of the extinguishing media is of first importance.

*More detailed information on portable fire extinguishers may be found in the Standard for the Installation, Maintenance and Use of Portable Fire Extinguishers (NFPA No. 10). Published by the National Fire Protection Association.

2084. It is recommended that temporary, appropriately worded danger markings or warning signs be posted throughout vessels where required, while vessels are in repair yard. Sample wordings of such signs are: Smoking Prohibited—Danger Fuel Oil—Paint Storage Positively No Hot Work—Cork Insulation No Welding or Burning—Carbon Dioxide Do Not Enter.

2085. Where there is any danger of starting fires in way of hot work, despite the fact that other ordinary precautions are employed, a fire watch should be provided to stand by during such operations with portable fire fighting equipment readily at hand to extinguish any incipient fire that may occur.

209. Temporary Electrical Installations.

2091. The vessel's lighting system should be used insofar as practical, except as prohibited in Paragraph 206, supplied either by self-generated power or from shore to ship connections.

2092. Where temporary portable electric lights must be used, they should be made up with substantial rubber-covered wire, and with substantial metal guards over lights. Where temporary artificial lighting is needed in hazardous areas, only approved explosion-proof lighting fixtures should be used.

2093. Temporary electrical wiring should be installed in a safe manner and should be properly fused. Such wiring and lamps should not be placed in direct contact with combustible materials. Makeshift hangers such as nails which might damage wiring insulation should not be used. Substantial wire guards should be installed on all lights subject to physical damage.

210. Stability—Fire Fighting.

2101. In the event of a fire due discretion should be used in the discharge of water into any under-deck compartment of a vessel, particularly the shelter decks or between decks. Measures to prevent overturning should be taken to the extent practicable when conditions indicate a threatening loss of stability.

2102. In locations where carbon dioxide gas is readily available in adequate quantities, this medium of extinguishment should preferably be employed in order that the vessel's stability be not endangered. Otherwise, if water is used, the vessel's pumping facilities should be in condition and ready to free the bilges of water wherever it tends to accumulate, in which connection it is impor-

tant that all scuppers leading from all decks below main deck to the bilge be maintained free and open.

2103. Where more than one vessel is berthed at the same pier or in the same wet basin, provision should be made for the withdrawal of any vessel in the event that fire makes such withdrawal necessary.

3. VESSELS DURING LAY-UP.

300. The following recommendations are intended for application with respect to vessels laid up for indefinite periods without personnel resident aboard.

301. Lay-Up Berth.

3011. Where the lay-up berth is contiguous to a wharf, pier, or other land-connected structure, it should be free from exposure to potential fire and explosion hazards, easy of access for fire fighting equipment, and within convenient proximity of adequate fire fighting facilities and water supply therefor. It should have sufficient depth of water at all stages of the tide to permit removal of the vessel in the event of fire.

3012. The wharf or pier should be in good repair and provided with adequate means for the safe mooring of vessels. Piers and wharves constructed and protected in accordance with the standards of the National Fire Protection Association* are recommended for vessel lay-up.

3013. A fire alarm box, telephone, or other reliable means of communication should be conveniently available and readily accessible.

3014. Vessels laid up in such numbers as to constitute a fleet should be separated in small groups to reduce the danger of fire-spread. The degree of separation of vessels or groups thereof should be determined by the size of the vessels, the character of their construction as to combustible materials, and the prevailing winds at the site of lay-up.

3015. Mooring of vessels, whether singly or in groups, should be effected in such manner as to facilitate their quick removal in the event of fire.

3016. Where vessels are to be laid up some distance from shore facilities, *e.g.*, at anchor, the site should be chosen with due regard to the availability of adequate fire fighting forces and equipment, and arrangements should be made in advance for obtaining prompt response of such facilities in case of need.

*See Standard for the Construction and Protection of Piers and Wharves (NFPA No. 87) published by the National Fire Protection Association.